



LIFETIME LED

WWW.LIFETIMELEDLIGHTS.COM

Year Range		Auto Make/Model	Low	High	Fog	Cornering
Start	End	ACURA				
2016	2016	ILX	-	-	H11	-
2013	2015	ILX	H11	9005	H11	-
2007	2013	MDX	-	9005	H11	-
2004	2006	MDX	H11	9005	9006	-
2002	2005	NSX	-	9005	9006	-
2016	2016	RDX	-	-	H11	-
2013	2015	RDX	H11	9005	H11	-
2007	2012	RDX	-	9005	H11	-
2009	2012	RL	-	9005	H8	-
2005	2008	RL	-	9005	H11	-
2005	2006	RSX	H11	9005	-	-
2009	2014	TL	-	9005	H11	-
2007	2008	TL	-	-	H8	-
2004	2006	TL	-	-	9006	-
2009	2014	TSX	-	9005	H11	-
2004	2008	TSX	-	H11	H11	-
2010	2013	ZDX	-	9005	H11	-
Start	End	AUDI				
2015	2016	A3	H7	-	H8	H8
2009	2013	A3	H7	H7	H11	-
2006	2008	A3	H11	H7	H7 H11	-
2006	2008	A3 w/ ADAPTIVE HID H/L	-	H7	H7 H11	-
2015	2016	A4	-	-	H8	H7
2013	2014	A4	H7	H7	H8	-
2009	2012	A4	H7	H7	H11	-
2002	2008	A4	H7	H7	H11	-
2015	2016	A5	-	-	H8	H7
2012	2014	A5	H7	H7	H8	-
2010	2012	A5	H7	-	H11	-
2008	2009	A5	H7	H7	H11	-
2015	2016	A6	-	-	H11	H7
2009	2014	A6	H7	-	H11	-
2005	2008	A6	H7	H11	H7	-
2015	2015	A7	-	-	-	H7
2012	2014	A7	-	-	-	H7 H11
2009	2010	A8	-	-	H11	-
2005	2008	A8	-	H7	H7	-
2015	2016	ALLROAD	-	-	H11	H7
2013	2014	ALLROAD	H7	H7	H11	-
2003	2005	ALLROAD	H1	H9	H7	-
2015	2016	Q3	-	-	H11	H8
2015	2016	Q5	-	-	H11	H7
2009	2014	Q5	H7	H7	H11	-
2015	2015	Q7	-	-	H11	H7
2010	2014	Q7	H7	-	H11	-
2007	2009	Q7	H7	H7	H7	-
2007	2008	RS4	-	-	H11	-
2013	2015	RS5	-	-	-	H7
2015	2015	S3	-	-	-	H7
2013	2015	S4	-	-	H8	H7

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2009	2012	S4	-	-	H11	-
2007	2008	S4	H7	H7	H11	-
2004	2006	S4	H7	H7	H11	-
2013	2015	S5	-	-	H8	H7
2008	2012	S5	-	-	H11	-
2015	2015	S6	-	-	H11	-
2009	2011	S6	-	-	H7	H8
2007	2008	S6	H7	H1	H7	-
2013	2014	S7	-	-	-	H7
2009	2009	S8	-	-	H11	H7
2007	2008	S8	-	H7	H7	-
2014	2015	SQ5	-	-	H11	H7
2013	2015	TT	-	-	H11	-
2008	2012	TT	H7	H7	H11	-
2000	2006	TT	H1	H7	H3	-
Start	End	BMW				
2012	2013	1 SERIES	H7	H7	H8	-
2008	2011	1 SERIES	H7	H7	H11	-
2014	2016	2 SERIES COUPE	H7	*	H8 H11	-
2014	2016	3 SERIES	H7	H7	H8	-
2011	2013	3 SERIES COUPE	-	-	H8 H11	-
2007	2010	3 SERIES COUPE	-	-	H8	-
2000	2006	3 SERIES COUPE	H7	H7	9006	-
2009	2013	3 SERIES SEDAN	H7	H7	H8	-
2007	2008	3 SERIES SEDAN	H7	H7	H11	-
2002	2006	3 SERIES SEDAN	H7	H7	H11	-
2014	2016	4 SERIES	-	-	H8	-
2014	2016	5 SERIES	-	-	-	H7
2011	2013	5 SERIES	-	-	H8	-
2008	2010	5 SERIES	H7	H7	H8	-
2004	2007	5 SERIES	H7	H7	-	-
2012	2015	6 SERIES	-	-	-	H7
2008	2010	6 SERIES	-	H7	H11	-
2004	2007	6 SERIES	-	H7	9006	-
2013	2015	7 SERIES	-	-	-	H7
2009	2012	7 SERIES	-	-	H8	-
2006	2008	7 SERIES	-	H7	9006	-
2002	2005	7 SERIES	-	H7	H3	-
2014	2015	i3	H7	H11	-	-
2012	2013	M3	-	-	H11	-
2009	2011	M3 COUPE	-	-	H11	-
2009	2011	M3 SEDAN	-	-	9006	-
2008	2008	M3	-	-	H11	-
2002	2006	M3	H7	H7	9006	-
2012	2016	M5	-	-	H11	H7
2008	2010	M5	-	-	9006	-
2006	2007	M5	H7	H7	9006	-
2012	2014	M6	-	-	-	H7
2006	2010	M6	-	H7	-	-
2012	2016	X1	H7	H7	H8	-
2015	2016	X3	H7	H7	-	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2011	2014	X3	H7	H7	H8 H11	-
2007	2010	X3	H7	H7	H11	-
2004	2006	X3	H7	H7	H11	-
2014	2016	X5	-	-	-	H7
2009	2013	X5	H7	H1	H11	-
2007	2008	X5	H7	H1	H11	-
2005	2006	X5	H7	H1	H11	-
2013	2014	X6	-	-	H8 H11	-
2008	2012	X6	-	-	H11	-
2003	2008	Z4	H7	H7	H11	-
Start	End	BUICK				
2010	2010	ALLURE	H11	H9	H11	-
2005	2009	ALLURE	H11	H9	H11	-
2016	2016	CASCADA	-	-	H11	H7
2004	2005	CENTURY	9006	9005	-	-
2008	2012	ENCLAVE	-	-	H11	-
2013	2016	ENCORE	H11	9005	H11	-
2014	2016	LACROSSE w/ HID	-	-	H8	-
2010	2013	LACROSSE	H11	H9	H11	-
2005	2009	LACROSSE	H11	H9	H11	-
1999	2005	LESABRE	9006	9005	-	-
2006	2011	LUCERNE	9006	9005	H11	-
1992	2005	PARK AVENUE	9006	9005	-	-
2004	2007	RAINIER	9006	9005	H11	-
2014	2016	REGAL	-	-	H10	-
2011	2013	REGAL	H11	H7	H10	-
2002	2007	RENDEVOUS	9006	9005	880	-
2005	2007	TERREZA	H11	H11	-	-
2012	2016	VERANO	H11	H9	H11	-
Start	End	CADILLAC				
2015	2015	CTS Coupe	-	-	H11	-
2014	2014	CTS COUPE/WAGON	H11	H9	H11	-
2014	2014	CTS-V SEDAN	-	-	H11	-
2008	2013	CTS	H11	H9	H11	-
2003	2007	CTS	-	-	H10	-
2000	2005	DEVILLE	9006	9005	880	-
2007	2014	ESCALADE	-	-	H10	-
2003	2006	ESCALADE	-	9005	880	-
2010	2016	SRX	H11	9005	H10	-
2006	2009	SRX	-	H7	H10	-
2005	2011	STS	H11	9005	H3	-
2006	2009	STS-V	-	9005	H3	-
2009	2009	XLR	-	-	H11	-
Start	End	CHEVROLET				
1995	2005	ASTRO VAN	9006	9005	-	-
2010	2013	AVALANCHE	H11	9005	-	-
2007	2009	AVALANCHE	H11	9005	-	-
2002	2006	AVALANCHE	9006	-	-	-
2009	2011	AVEO	H4	*	H3	-
2004	2008	AVEO	H4	*	881	-
2009	2011	AVEO-5	H4	*	H3	-
2005	2008	AVEO-5	H4	*	881	-



Year Range		Auto Make/Model	Low	High	Fog	Cornering
1998	2005	BLAZER	9006	9005	881	-
2014	2015	CAMARO Z28	H13	*	-	-
2014	2016	CAMARO w/o HID	H11	H9	-	-
2014	2015	CAMARO ZL1	-	-	H11	-
2012	2013	CAMARO	H13	*	H11	-
2010	2011	CAMARO	H13	*	-	-
2011	2016	CAPRICE	H11	H7	-	-
2000	2005	CAVALIER	9007	*	880	-
2015	2016	CITY EXPRESS	H13	*	-	-
2005	2010	COBALT	9007	*	H11	-
2015	2016	COLORADO	H11	9005	-	-
2004	2012	COLORADO	9006	9005	H10	-
2005	2013	CORVETTE	-	H9	H10	-
2016	2016	CRUZE	H11	9005	H11	-
2011	2016	CRUZE LIMITED	H13	*	H8	-
2016	2016	EQUINOX	H11	9005	H8	-
2010	2015	EQUINOX	H11	9005	H11	-
2005	2009	EQUINOX	9007	*	H11	-
1996	2016	EXPRESS CONVERSION	9006	9005	-	-
2006	2011	HHR	H13	*	H10	-
2014	2016	IMPALA LIMITED	H11	H9	H11	-
2006	2013	IMPALA	H11	H9	H11	-
2000	2005	IMPALA	9006	9005	-	-
2016	2016	MALIBU	9005	*	-	-
2013	2016	MALIBU LS	H11	9005	-	-
2013	2016	MALIBU LT	H11	H7	H10	-
2013	2016	MALIBU LTZ	H11	H7	H10	-
2007	2012	MALIBU	H11	H9	H11	-
2004	2006	MALIBU	H11	H9	880	-
2006	2007	MONTE CARLO	H11	H9	H11	-
2000	2005	MONTE CARLO	9006	9005	880	-
2015	2016	SILVERADO HD	H11	9005	-	-
2007	2015	SILVERADO	H11	9005	-	-
2003	2007	SILVERADO	9006	9005	H10	-
2012	2016	SONIC	H11	9005	H8	-
2016	2016	SPARK	H13	*	-	-
2013	2015	SPARK	H13	*	H11	-
2016	2016	SS	-	H9	-	-
2014	2015	SS	-	H9	H10	-
2003	2006	SSR	H11	-	880	-
2007	2016	SUBURBAN	H11	9005	-	-
2000	2006	SUBURBAN	9006	9005	880	-
2007	2016	TAHOE	H11	9005	-	-
2000	2006	TAHOE	9006	9005	880	-
2002	2009	TRAILBLAZER	9006	9005	880	-
2013	2016	TRAVERSE	H11	H7	-	-
2010	2012	TRAVERSE	H11	9005	-	-
2013	2016	TRAX	H7	H1	H8	-
2005	2009	UPLANDER	H11	H11	-	-
1997	2005	VENTURE	9004	*	-	-
2016	2016	VOLT	-	9005	-	-
Start	End	CHRYSLER				
2016	2016	200	9005	*	-	-
2013	2015	200	-	-	H11	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2016	2016	300	9005	*	-	-
2011	2014	300 w/ HID	-	-	H11	-
2005	2010	300	9006	9005	H10	-
2005	2010	300C	-	9005	H10	-
2007	2009	ASPEN	H13	*	H10	-
2004	2008	CROSSFIRE	H7	H7	9006	-
2007	2008	PACIFICA	H13	*	H10	-
2005	2006	PACIFICA	H7	H7	H10	-
2006	2010	PT CRUISER	-	-	H10	-
2001	2005	PT CRUISER	-	-	9006	-
2007	2010	SEBRING SEDAN	9006	9005	H10	-
1999	2006	SEBRING SEDAN	9007	*	880	-
2007	2010	SEBRING CONVERTIBLE	9007	*	9006	-
1999	2006	SEBRING CONVERTIBLE	9007	*	9006	-
2010	2016	TOWN & COUNTRY	H11	H11	-	-
2008	2009	TOWN & COUNTRY	H11	H11	H10	-
2005	2008	TOWN & COUNTRY	9007	*	H10	-
Start	End	DODGE				
2013	2014	AVENGER	9006	9005	H11	-
2010	2012	AVENGER	9006	9005	-	-
2008	2009	AVENGER	9006	9005	H10	-
2010	2012	CALIBER	H13	*	-	-
2007	2009	CALIBER	H13	*	H10	-
2005	2007	CARAVAN	9007	*	H10	-
1996	2005	CARAVAN	9007	*	-	-
2011	2014	CHALLENGER	H13	*	-	-
2009	2010	CHALLENGER	H13	9005	H10	-
2008	2008	CHALLENGER	-	9005	H10	-
2016	2016	CHARGER	9005	*	-	-
2011	2014	CHARGER	H11	9005	-	-
2006	2009	CHARGER	-	-	H10	-
2010	2010	DAKOTA	H13	*	-	-
2005	2009	DAKOTA	H13	*	H10	-
2016	2016	DART	9005	*	H11	-
2013	2015	DART	-	-	H11	-
2016	2016	DURANGO	9005	*	H11	-
2014	2015	DURANGO	-	-	H11	-
2011	2013	DURANGO	H11	9005	-	-
2007	2009	DURANGO	H13	*	H10	-
2004	2006	DURANGO	H13	*	9006	-
2011	2016	GRAND CARAVAN	H11	H11	-	-
2010	2010	GRAND CARAVAN	H13	*	-	-
2008	2009	GRAND CARAVAN	H13	*	H10	-
2010	2016	JOURNEY	9006	9005	-	-
2009	2009	JOURNEY	9006	9005	H10	-
2005	2008	MAGNUM	9006	9005	H10	-
2001	2005	NEON	9007	*	H10	-
2007	2011	NITRO	H13	*	H10	-
2010	2010	RAM PICKUP	H13	*	H10	-
2009	2010	RAM PICKUP w/ 4 HEADLAMP SYSTEM	H11	9005	H10	-
2006	2009	RAM PICKUP	H13	*	9006	-
2003	2005	RAM PICK-UP	9007	*	9006	-
2007	2009	SPRINTER	H7	H7	H11	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2005	2006	SPRINTER	H7	H1	H1	-
2001	2006	STRATUS	9007	*	880	-
2003	2010	VIPER	-	-	H10	-
Start	End	FIAT				
2012	2016	500	-	-	H11	-
2014	2016	500L	-	-	H11	-
2016	2016	500X	-	-	H8	-
Start	End	FORD				
2013	2016	C-MAX	H11	H1	H11	-
1998	2011	CROWN VICTORIA	9007	*	-	-
2008	2016	ECONOLINE	H13	*	-	-
1992	2007	ECONOLINE	9007	*	-	-
2015	2016	EDGE	H11	9005	-	-
2007	2010	EDGE	H11	9005	H11	-
2013	2016	ESCAPE S	H11	9005	-	-
2013	2016	ESCAPE SE, SEL	H11	9005	H10	-
2013	2016	ESCAPE - TITANIUM	-	H1	H10	-
2008	2012	ESCAPE	H13	*	-	-
2007	2007	ESCAPE	H11	H7	-	-
2005	2006	ESCAPE	H11	H7	H10	-
2005	2005	EXCURSION	H13	*	H10	-
2015	2016	EXPEDITION w/ Projector	9005	H9	-	-
2015	2016	EXPEDITION w/o Projector	H11	9005	-	-
2013	2014	EXPEDITION	H13	*	-	-
2007	2012	EXPEDITION	H13	*	H10	-
2003	2006	EXPEDITION	9006	9005	H10	-
2016	2016	EXPLORER	-	9005	H10	-
2011	2015	EXPLORER	9005	*	H11	-
2006	2010	EXPLORER	H13	*	H10	-
2002	2005	EXPLORER	9006	9005	H10	-
2007	2010	EXPLORER SPORT TRAC	H13	*	H10	-
2001	2005	EXPLORER SPORT TRAC	9007	*	H10	-
2015	2016	F-150	H11	9005	-	-
2013	2014	F-150	H13	*	-	-
2006	2012	F-150	H13	*	-	-
2004	2005	F-150	H13	*	H10	-
2005	2016	F-SERIES SUPER DUTY	H13	*	H10	-
2014	2016	FIESTA	H11	H1	-	-
2011	2013	FIESTA	H11B	9005	H11	-
2005	2007	FIVE HUNDRED	9006	9005	H10	-
2009	2016	FLEX	H13	*	H11	-
2015	2016	FOCUS	H11	H1	H8	-
2012	2014	FOCUS	H11	H1	H11	-
2008	2011	FOCUS	H13	*	H11	-
2005	2007	FOCUS	9007	*	H11	-
2004	2007	FREESTAR	H13	*	-	-
2005	2007	FREESTYLE	H13	*	H11	-
2006	2016	FUSION	H11	H7	H11	-
2013	2016	MUSTANG	-	-	H11	-
2010	2012	MUSTANG	H13	*	H11	-
2005	2009	MUSTANG	H13	*	H11	-
2005	2006	MUSTANG GT	-	-	H1	-
2013	2015	POLICE INTERCEPTOR UTILITY	9005	*	-	-
2001	2011	RANGER	9007	*	H10	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2010	2014	RAPTOR	H13	*	-	-
2010	2012	TAURUS	9005	*	-	-
2008	2009	TAURUS - incl. X	H11	9005	H11	-
1992	2007	TAURUS	9007	*	880	-
2002	2005	THUNDERBIRD	9007	*	-	-
2015	2016	TRANSIT	H11	9005	-	-
2014	2016	TRANSIT CONNECT	H11	H9	H11	H11
2010	2013	TRANSIT CONNECT	H13	*	H11	-
Start	End	FREIGHTLINER				
2007	2016	SPRINTER	H7	H7	H11	H7
2005	2006	SPRINTER	H7	H1	H1	-
Start	End	GMC				
2013	2016	ACADIA	-	-	H11	-
2007	2012	ACADIA	H11	H7	-	-
2015	2016	CANYON	H11	9005	-	-
2009	2012	CANYON	9006	9005	-	-
2004	2008	CANYON	9006	9005	H11	-
1999	2009	ENVOY	9006	9005	880	-
1995	2005	JIMMY	9006	9005	880 881	-
1995	2005	SAFARI	9006	9005	-	-
1996	2016	SAVANA	9006	9005	-	-
2007	2013	SIERRA	H11	-	-	-
2003	2006	SIERRA	9006	9005	H10	-
1999	2007	SIERRA CLASSIC	9006	9005	H10	-
2007	2010	SIERRA DENALI	H11	9005	-	-
2002	2006	SIERRA DENALI	9005	9005	880	-
2010	2016	TERRAIN	H11	9005	H11	-
2015	2016	YUKON	H11	9005	-	-
2007	2014	YUKON	H13	*	-	-
2000	2006	YUKON	9006	9005	880	-
2007	2008	YUKON DENALI	H13	*	-	-
2001	2006	YUKON DENALI	9005	9005	880	-
2008	2013	YUKON HYBRID	H13	*	H10	-
Start	End	HONDA				
2013	2016	ACCORD	H11	9005	H8	-
2006	2012	ACCORD	9006	9005	H11	-
1999	2005	ACCORD	9006	9005	-	-
2013	2016	ACCORD COUPE	H11	9005	H8	-
2008	2012	ACCORD COUPE	H11	9005	H11	-
2006	2007	ACCORD COUPE	9006	9005	H11	-
2010	2011	ACCORD CROSSTOUR	H11	9005	H11	-
2016	2016	CIVIC	H11	9005	H8	-
2006	2015	CIVIC	9006	9005	H11	-
2004	2005	CIVIC	9006	9005	-	-
2014	2015	CIVIC COUPE	H11	9005	H11	-
2009	2013	CIVIC COUPE	9006	9005	H11	-
2004	2008	CIVIC COUPE	9006	9005	-	-
2012	2015	CIVIC HYBRID	9006	9005	-	-
2009	2011	CIVIC HYBRID	9006	9005	H11	-
2006	2008	CIVIC HYBRID	9006	9005	-	-
2015	2016	CR-V	H11	9005	H8	-
2012	2014	CR-V	H4	*	H11	-
2007	2011	CR-V	H4	*	-	-



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2005	2006	CR-V	H1	H1	-	-
2013	2016	CR-Z	H11	9005	H8	-
2011	2012	CR-Z	H11	9005	H11	-
2012	2015	CROSSTOUR	H11	9005	H11	-
2003	2011	ELEMENT	H4	*	-	-
2007	2008	ELEMENT SC	H11	9005	-	-
2015	2016	FIT	H4	*	H8	-
2007	2014	FIT	H4	*	-	-
2007	2014	FIT SPORT	H4	*	H11	-
2016	2016	HR-V	H4	*	H8	-
2010	2014	INSIGHT	H11	9005	-	-
2000	2006	INSIGHT	H4	*	-	-
2011	2016	ODYSSEY	H11	9005	H11	-
2008	2010	ODYSSEY	9006	9005	H11	-
2005	2007	ODYSSEY	9006	9005	H8	-
2016	2016	PILOT	H11	9005	H8	-
2006	2015	PILOT	H11	9005	H11	-
2003	2005	PILOT	H4	*	-	-
2006	2014	RIDGELINE	H4	*	H11	-
2000	2009	S2000	-	H1	-	-
Start	End	HUMMER				
2003	2009	H2	9007	*	-	-
2006	2010	H3	H13	*	-	-
Start	End	HYUNDAI				
2014	2016	ACCENT w/ PROJECTOR H/L	9005	*	881	-
2000	2016	ACCENT w/o PROJECTOR H/L	H4	*	881	-
2011	2016	AZERA	H7	H7	H8	-
2008	2010	AZERA	H11B	H7	H8	-
2006	2007	AZERA	H7	H7	H8	-
2014	2016	ELANTRA w/o PROJECTOR H/L	H11	H7	881	-
2014	2016	ELANTRA w/ PROJECTOR H/L	9005	H7	881	-
2014	2016	ELANTRA COUPE w/o PROJECTOR H/L	H11	H7	881	-
2014	2016	ELANTRA COUPE w/ PROJECTOR H/L	9005	H7	881	-
2013	2013	ELANTRA COUPE	H11	H1	881	-
2013	2016	ELANTRA GT	H11	H7	881	-
2007	2012	ELANTRA SEDAN	H11B	H1	881	-
2009	2012	ELANTRA WAGON	H11B	H7	881	-
2004	2006	ELANTRA	H7	H1	9006	-
2008	2009	ENTOURAGE	H11B	H7	9006	-
2007	2007	ENTOURAGE	H7	H7	9006	-
2014	2016	EQUUS	-	H7	-	-
2011	2013	EQUUS	-	H7	H8	-
2015	2015	GENESIS	H11	9005	-	-
2009	2014	GENESIS	H11	H7	H8	-
2013	2016	GENESIS COUPE	H7	H7	H8	-
2010	2012	GENESIS COUPE	H11B	H1	881	-
2013	2016	SANTA FE	H11	H7	H8	-
2009	2012	SANTA FE	H11B	H7	881	-
2007	2008	SANTA FE	H7	H7	881	-
2002	2006	SANTA FE	H4	*	H3	-
2015	2016	SONATA	9005	9005	-	-
2011	2014	SONATA	H7	H7	H8	-
2009	2010	SONATA	H11B	H1	881	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2006	2008	SONATA	H7	H1	881	-
2002	2005	SONATA	H7	H1	9006	-
2011	2015	SONATA HYBRID	H11	H7	H8	-
2015	2015	SONATA SPORT	9005	9005	-	-
2007	2008	TIBURON	H11	H7	9006	-
2003	2006	TIBURON	H7	H7	9006	-
2014	2015	TUCSON	-	-	880	-
2010	2013	TUCSON	H4	*	880	-
2005	2009	TUCSON	H4	*	881	-
2012	2015	VELOSTER	H7	H7	881	-
2012	2012	VELOSTER w/ PROJECTOR H/L	H11B	H7	881	-
2013	2015	VELOSTER TURBO	H11B	H7	H8	-
2010	2012	VERACRUZ	H11B	H7	9006	-
2007	2009	VERACRUZ	H11	H7	9006	-
2002	2005	XG350	H7	H1	-	-
Start	End	INFINITI				
2008	2012	EX35	H11	H9	H8	-
2013	2013	EX37	H11	H9	H8	-
2006	2012	FX35	-	-	H8	-
2003	2005	FX35	-	-	9006	-
2013	2013	FX37	-	-	H8	-
2006	2008	FX45	-	-	H8	-
2003	2005	FX45	-	-	9006	-
2009	2013	FX50	-	-	H8	-
2011	2012	G25	-	-	H8	-
2007	2008	G35	-	-	9006	-
2006	2006	G35	-	-	H4	-
2003	2005	G35	H1	H4	H4	-
2006	2007	G35 COUPE	-	-	H1	-
2014	2014	G37	-	-	H8	-
2011	2013	G37	-	-	H8	-
2009	2013	G37	-	-	9006	-
2008	2008	G37	-	-	H1	-
2011	2013	G37 COUPE	-	-	H11	-
2009	2010	G37 COUPE	-	-	H1	-
2013	2013	JX35	-	-	H11	-
2009	2010	M35	-	9005	H11	-
2006	2008	M35	H1	9005	H11	-
2012	2013	M35h	-	-	H8	-
2011	2013	M37	-	-	H8	-
2009	2010	M45	-	9005	H11	-
2006	2008	M45	H1	9005	H11	-
2011	2013	M56	-	-	H8	-
2015	2015	Q40	-	-	H8	-
2005	2006	Q45	-	9005	H8	-
2014	2015	Q60	-	-	H11	-
2014	2014	Q70	-	-	H8	-
2016	2016	QX50	H11	H9	-	-
2014	2015	QX50	H11	H9	H8	-
2011	2013	QX56	-	-	H8	-
2004	2010	QX56	-	9005	H3	-
2014	2015	QX60	-	-	H11	-
2014	2016	QX70	-	-	H8	-
2014	2014	QX80	-	-	H8	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
Start	End	ISUZU				
2003	2008	ASCENDER	9006	9005	880	-
2006	2006	i-280	9006	9005	-	-
2007	2008	i-290	9006	9005	-	-
2006	2006	i-350	9006	9005	-	-
2007	2008	i-370	9006	9005	-	-
Start	End	JAGUAR				
2004	2008	S-TYPE	H7	9005	H11	-
2009	2009	SUPER V8	-	H7	H11	-
2007	2008	SUPER V8	H7	H7	H3	-
2005	2006	SUPER V8	H7	H7	9006	-
2009	2009	VANDEN PLAS	-	H7	H11	-
2007	2008	VANDEN PLAS	H7	H7	H3	-
2004	2006	VANDEN PLAS	H7	H7	9006	-
2004	2008	X-TYPE	H1	H1	H11	-
2009	2011	XF	H11	H7	-	-
2004	2009	XJ8	H7	H7	H3	-
2004	2009	XJR	H7	H7	H3	-
2007	2015	XK	-	-	-	H8
2003	2006	XK8	H1	9005	H1	-
2007	2014	XKR	-	-	-	H8
2003	2006	XKR	H1	9005	H1	-
Start	End	JEEP				
2016	2016	CHEROKEE	9005	*	-	-
2006	2010	COMMANDER	9006	9005	H10	-
2014	2016	COMPASS	H11	9005	H11	-
2011	2013	COMPASS	H11	9005	-	-
2010	2010	COMPASS	H13	*	-	-
2007	2009	COMPASS	H13	*	H10	-
2014	2015	COMPASS LIMITED	-	-	H11	-
2014	2016	GRAND CHEROKEE	H11	9005	H11	-
2011	2013	GRAND CHEROKEE	H11	9005	-	-
2008	2010	GRAND CHEROKEE	9006	9005	H10	-
2005	2007	GRAND CHEROKEE	9006	9005	H10	-
2012	2013	GRAND CHEROKEE SRT8	-	9005	H11	-
2008	2012	LIBERTY	H13	*	H10	-
2002	2007	LIBERTY	9007	*	H10	-
2010	2016	PATRIOT	H13	*	-	-
2007	2009	PATRIOT	H13	*	H10	-
2015	2016	RENEGADE	H13	*	H11	-
1999	2006	TJ	-	-	H3	-
2010	2016	WRANGLER	H13	*	-	-
2007	2009	WRANGLER	H13	*	H10	-
1999	2006	WRANGLER	-	-	H3	-
Start	End	KIA				
2007	2009	AMANTI	H11	H7	-	-
2004	2006	AMANTI	H7	H7	H3	-
2009	2011	BORREGO	H11B	H1	881	-
2014	2016	CADENZA	H7	H9	H8	-
2014	2015	CADENZA LIMITED	-	H9	-	-
2014	2016	FORTE	H11	H1	H8	-
2010	2013	FORTE	H11B	H1	881	-
2015	2015	K900 w/ HID	-	9005	-	-
2014	2015	OPTIMA EX, LX, SX	H11B	H1	H8	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2014	2015	OPTIMA HYBRID	H11B	H1	-	-
2014	2015	OPTIMA LIMITED	-	H7	-	-
2014	2015	OPTIMA SX TURBO	-	H7	H8	-
2011	2013	OPTIMA	H11B	H1	H8	-
2009	2010	OPTIMA	H11B	H1	881	-
2007	2008	OPTIMA	H11B	H1	9006	-
2006	2007	OPTIMA	H7	H1	9006	-
2005	2005	OPTIMA	H7	H7	H1	-
2000	2011	RIO	H4	*	881	-
2012	2015	RIO HATCHBACK w/ PROJECTOR H/L	H11B	H1	9006	-
2012	2015	RIO HATCHBACK w/o PROJECTOR H/L	H7	H1	9006	-
2012	2015	RIO SEDAN	H4	*	H8	-
2006	2006	RIO 5	H4	*	-	-
2014	2016	RONDO	H11B	H7	H8	-
2007	2012	RONDO	H11B	H1	881	-
2014	2014	SEDONA	H11B	H1	H8	-
2007	2012	SEDONA	H11B	H1	H8	-
2006	2007	SEDONA	H7	H1	H8	-
2002	2005	SEDONA	H7	H7	881	-
2015	2015	SEDONA L, LX	H7	H7	-	-
2015	2015	SEDONA EX, SX	H7	H7	H8	-
2015	2015	SEDONA LIMITED	H7	H7	9006	-
2011	2013	SORENTO	H11	H1	881	-
2007	2009	SORENTO	H11B	H1	881	-
2003	2006	SORENTO	H7	H1	881	-
2014	2016	SORENTO EX, LX, SX	H7	H7	881	-
2015	2016	SORENTO LIMITED	-	H7	881	-
2014	2016	SOUL wo/ PROJECTOR H/L	H7	H7	H8	-
2014	2016	SOUL w/ PROJECTOR H/L	H13	*	H8	-
2014	2016	SOUL w/ HID H/L	-	H7	H8	-
2012	2013	SOUL	H11B	H7	881	-
2010	2011	SOUL	H4	*	881	-
2015	2016	SOUL EV	H7	H7	9006	-
2005	2009	SPECTRA	H4	*	881	-
2005	2009	SPECTRA 5	H4	*	881	-
2014	2016	SPORTAGE	H11B	H7	881	-
2011	2013	SPORTAGE	H11B	H7	881	-
2005	2010	SPORTAGE	H4	*	881	-
Start	End	LAMBORGHINI				
Start	End	LAND ROVER				
2016	2016	DISCOVERY SPORT	H11	-	-	-
2004	2005	FREELANDER	H7	H7	H3	-
2011	2015	LR2	H11	H7	H11	-
2008	2010	LR2	H11	H7	H11	-
2008	2009	LR3	H7	H7	H11	-
2005	2007	LR3	H7	H7	H11	-
2016	2016	LR4	H11	H7	H11	-
2010	2015	LR4	H7	H7	H11	-
2010	2012	RANGE ROVER	-	-	H11	-
2006	2008	RANGE ROVER	-	H7	H11	-
2002	2005	RANGE ROVER	H7	H7	H7	-
2012	2016	RANGE ROVER EVOQUE	9005	*	-	-
2010	2016	RANGE ROVER SPORT	-	-	H11	-

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2006	2009	RANGE ROVER SPORT	H7	H7	H11	-
Start	End	LEXUS				
2014	2016	CT200H	H11	H9	H16	-
2011	2013	CT200H	H11	H9	H11	-
2016	2016	ES300H	-	H9	-	-
2013	2015	ES300H	H11	9005	H16	-
2004	2006	ES330	H11	9005	9006	-
2016	2016	ES350	-	H9	-	-
2013	2015	ES350	H11	9005	H16	-
2011	2012	ES350	H11	9005	9006	-
2007	2010	ES350	H7	9005	9006	-
2005	2006	GS300	-	9005	9006	-
2014	2015	GS350	-	-	H16	-
2013	2013	GS350	-	-	H11	-
2007	2011	GS350	-	9005	9006	-
2005	2007	GS430	-	9005	9006	-
2014	2015	GS450H	-	-	H16	-
2013	2014	GS450H	-	-	H11	-
2007	2011	GS450H	-	9005	9006	-
2008	2011	GS450H	-	9005	9006	-
2008	2011	GS460	-	9005	9006	-
2014	2016	GX460	-	H9	-	-
2010	2013	GX460	H11	9005	H11	-
2003	2009	GX470	H11	9005	H3	-
2010	2012	HS250H	H11	9005	H11	-
2014	2014	IS F	-	9005	-	-
2008	2013	IS F	-	9005	H11	-
2014	2014	IS250 / IS350	-	-	H16	-
2011	2013	IS250 / IS350	H11	9005	H11	-
2006	2010	IS250 / IS350	H11	9005	9006	-
2010	2015	IS250C / IS350C	H11	9005	H11	-
2003	2005	IS300	-	9005	H3	-
2007	2012	LS460	-	9005	9006	-
2008	2012	LS600H	-	9005	9006	-
1999	2007	LX470	H1	9005	H3	-
2013	2015	LX570	-	9005	H11	-
2008	2011	LX570	H11	9005	H11	-
2015	2016	NX200T	-	9005	-	-
2015	2016	NX300H	-	9005	-	-
2004	2006	RX330	H11	9005	9006	-
2014	2015	RX350	H11	9005	H16	-
2010	2013	RX350	H11	9005	H11	-
2007	2009	RX350	H11	9005	9006	-
2006	2008	RX400H	H11	9005	H11	-
2014	2015	RX450H	H11	9005	H16	-
2014	2015	RX450H w/ HID	-	9005	-	-
2014	2014	RX450H w/ LED H/L	-	H9	H16	-
2010	2013	RX450H	H11	9005	H11	-
2002	2010	SC430	-	9005	H3	-
Start	End	LINCOLN				
2003	2005	AVIATOR	H11	9005	-	-
2005	2006	LS	H11	9005	H10 H11	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2005	2006	LS W/HID H/L	-	H11	H10	-
					H11	
2006	2008	MARK LT	H13	*	-	-
2009	2016	MKS	-	-	H11	-
2010	2016	MKT	-	-	H11	-
2011	2015	MKX	-	-	H11	-
2007	2010	MKX	H11	9005	H11	-
2010	2012	MKZ	H11	H7	H11	-
2007	2009	MKZ	H11	H7	H11	-
2007	2014	NAVIGATOR	-	-	H11	-
2003	2006	NAVIGATOR	9006	9005	H10	-
2004	2011	TOWN CAR	H7	9005	H10	-
2003	2010	TOWN CAR	H7	9005	H10	-
Start	End	LOTUS				
2004	2006	ELISE	H1	H7	-	-
Start	End	MAYBACH				
2003	2012	57, 62	-	H7	H3	-
Start	End	MAZDA				
2011	2014	2	H4	*	H11	-
2014	2016	3 HATCHBACK	H11	9005	H11	-
2010	2013	3 HATCHBACK	H11	9005	H11	-
2014	2016	3 SEDAN	H11	9005	H11	-
2010	2013	3 SEDAN	H11	9005	H11	-
2007	2009	3 SEDAN	H7	9005	9006	-
					H11	
2004	2006	3 SEDAN	H7	9005	H11	-
2012	2015	5	H11	9005	H11	-
2006	2010	5	H7	9005	H11	-
2016	2016	6	H11	9005	-	-
2014	2015	6	H11	9005	H11	-
2011	2013	6	H7	9005	H11	-
2009	2010	6	H7	H9	H11	-
2006	2008	6	H1	H1	H11	-
2003	2005	6	H1	H1	H3	-
2006	2010	B SERIES PICK-UP	9007	*	9006	-
2016	2016	CX-3	H11	9005	-	-
2013	2016	CX-5	H11	9005	H11	-
2007	2012	CX-7	H7	9005	H11	-
2013	2015	CX-9	H11	9005	H11	-
2007	2012	CX-9	H11	9005	9006	-
2004	2006	MPV	H4	*	H11	-
2006	2015	MX-5 MIATA	H7	H9	H11	-
2004	2005	MIATA	9006	9005	9006	-
2009	2011	RX-8	H7	H9	9006	-
2004	2008	RX-8	H7	H9	H11	-
2008	2011	TRIBUTE	H13	*	H10	-
2001	2006	TRIBUTE	H4	*	H1	-
Start	End	MERCEDES-BENZ				
2013	2016	B-CLASS	H7	H7	-	-
2016	2016	C-CLASS	H7	H7	-	-
2011	2015	C-CLASS	H7	H7	H7	-
2008	2010	C-CLASS	H7	H7	H7	-
					H11	
2003	2007	C-CLASS	H7	H7	9006	-

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2011	2014	CL-CLASS	-	H11	-	-
2010	2010	CL-CLASS	-	H7	H7	-
					H11	
2007	2009	CL-CLASS	-	H7	H7	-
					H11	
2001	2006	CL-CLASS	-	H7	9006	-
2014	2016	CLA-CLASS	H7	-	-	H7
2006	2009	CLK-CLASS	H7	H7	H7	-
					H11	
2004	2005	CLK-CLASS	H7	H7	9006	-
2006	2011	CLS-CLASS	H7	H7	H7	-
					H11	
2008	2012	E-CLASS	H7	H7	H11	-
2003	2007	E-CLASS	H7	H7	H11	-
					9006	
2007	2007	E280	H7	H7	-	-
2008	2009	E300	H7	H7	-	-
2011	2016	G-CLASS	-	-	H11	-
2008	2010	G-CLASS	H4	*	H11	-
2002	2007	G-CLASS	H4	*	H3	-
2013	2016	GL-CLASS	H7	H7	-	-
2012	2012	GL-CLASS	H7	H7	-	-
2008	2011	GL-CLASS	H7	H7	H11	-
2007	2007	GL-CLASS	H7	H7	H11	-
2015	2016	GLA-CLASS	H7	-	H11	-
2016	2016	GLE-CLASS	H7	H7	-	-
2013	2015	GLK-CLASS	H7	-	-	-
2010	2012	GLK-CLASS	H7	H7	H11	-
2012	2015	M-CLASS	H7	H7	-	-
2008	2011	M-CLASS	H7	H7	H7	-
					H11	
2006	2007	M-CLASS	H7	H7	H7	-
2002	2005	M-CLASS	H7	H7	H8	-
2016	2016	METRIS	H7	-	H11	-
2011	2013	R-CLASS	H7	H7	-	-
2006	2010	R-CLASS	H7	H7	H7	-
					H11	
2011	2013	S-CLASS	-	H9	-	-
2007	2010	S-CLASS	-	H7	H11	-
2003	2006	S-CLASS	H7	H7	H7	-
2008	2011	S450	H7	H9	-	-
2013	2016	SL-CLASS	-	-	H7	-
2009	2012	SL-CLASS	-	H7	H11	-
2007	2008	SL-CLASS	-	H7	H11	-
2003	2006	SL-CLASS	H7	H7	9006	-
2012	2016	SLK-CLASS	H7	H7	-	H7
2004	2011	SLK-CLASS	H7	H7	H7	-
					9006	
2005	2009	SLR MCLAREN	-	9005	H3	-
2010	2016	SPRINTER	H7	H7	H11	H7
Start	End	MERCURY				
2006	2011	GRAND MARQUIS	H13	*	H10	-
1998	2005	GRAND MARQUIS	9007	*	-	-
2005	2011	MARINER	H13	*	H10	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2010	2011	MILAN	9005	*	H11	-
2006	2009	MILAN	H11	H7	H11	-
2005	2007	MONTEGO	-	9005	H10	-
2004	2007	MONTEREY	H13	*	H1	-
2007	2010	MOUNTAINEER	H13	*	H10	-
2002	2006	MOUNTAINEER	9007	*	H10	-
2008	2009	SABLE	H11	9005	H11	-
1992	2005	SABLE	9007	*	-	-
Start	End	MINI				
2016	2016	COOPER COUPE / CONVERTIBLE	H13	*	H8	-
2009	2015	COOPER	H13	*	H8	-
2006	2006	COOPER	H7	H7	H11	-
2006	2006	COOPER w/ HID	-	H9	H11	-
2005	2005	COOPER	H7	H7	H11	-
2016	2016	COOPER CLUBMAN	H4	*	H8	-
2008	2014	COOPER CLUBMAN (incl. "S")	H13	*	H8	-
2007	2008	COOPER CONVERTIBLE (incl. "S")	H7	H7	H11	-
2011	2016	COOPER COUNTRYMAN	H13	*	H8	-
2016	2016	COOPER HATCHBACK	H4	*	H8	-
2007	2008	COOPER HATCHBACK (incl. "S")	H13	*	H8	-
2013	2016	COOPER PACEMAN	H13	*	H8	-
2009	2014	COOPER S	H13	*	H8	-
2006	2006	COOPER S	H7	H7	H11	-
2006	2006	COOPER S w/ HID	-	H9	H11	-
2005	2005	COOPER S	H7	H7	H11	-
2009	2014	JCW CLUBMAN	H13	*	H8	-
2009	2014	JOHN COOPER WORKS	H13	*	H8	-
Start	End	MITSUBISHI				
2009	2012	ECLIPSE	H13	*	H11	-
2008	2008	ECLIPSE	H13	*	H10	-
2006	2007	ECLIPSE	H13	*	H11	-
2003	2005	ECLIPSE	H4	*	H1	-
2006	2011	ENDEAVOR	9007	*	H11	-
2004	2005	ENDEAVOR	9007	*	H1	-
2010	2012	GALANT	9007	*	H10	-
2007	2009	GALANT	9007	*	H10	-
2007	2009	GALANT w/ PROJECTOR HEADLIGHTS	9006	9005	H10	-
2004	2006	GALANT	9007	*	H1	-
2004	2006	GALANT w/ PROJECTOR HEADLIGHTS	9006	9005	H1	-
2012	2016	I-MIEV	H11	9005	H8	-
2016	2016	LANCER	9006	9005	H16	-
2008	2015	LANCER	9006	9005	H11	-
2004	2007	LANCER	9007	*	H3	-
2005	2006	LANCER EVOLUTION	9006	9005	-	-
2005	2006	LANCER OZ RALLY	9007	*	H3	-
2005	2006	LANCER RALLIART	9007	*	H3	-
2014	2015	MIRAGE	H4	*	H11	-
2001	2006	MONTERO	H4	*	9006	-
2016	2016	OUTLANDER	H7	9005	H16	-
2014	2015	OUTLANDER	H7	9005	H11	-
2010	2013	OUTLANDER	9006	9005	H11	-
2007	2009	OUTLANDER	9006	9005	H11	-
2005	2006	OUTLANDER	H1	9005	9006	-

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2016	2016	OUTLANDER SPORT	H11	9005	H16	-
2011	2015	OUTLANDER SPORT	H11	9005	H11	-
2006	2009	RAIDER	H13	*	H10	-
2015	2015	RVR	H11	9005	H11	-
Start	End	NISSAN				
2003	2005	350Z	H7	H1	-	-
2003	2005	350Z w/ HID	-	H7	-	-
2007	2016	ALTIMA	H11	H9	H11	-
2005	2006	ALTIMA	H1	9005	H11	-
2011	2015	ARMADA	9006	9005	H11	-
2004	2010	ARMADA	9006	9005	-	-
2009	2014	CUBE	H4	*	H8	-
2005	2016	FRONTIER	9007	*	H11	-
2009	2014	GT-R	-	H9	-	-
2015	2016	JUKE	H11	9005	H11	-
2011	2014	JUKE	9007	*	H8	-
2013	2016	LEAF	H13	*	H11	-
2011	2016	LEAF w/ LED HEADLIGHTS	-	H9	H11	-
2016	2016	MAXIMA	H11	H9	H16	-
2009	2014	MAXIMA	H11	9005	H11	-
2008	2008	MAXIMA	9005	9005	H11	-
2007	2007	MAXIMA	-	-	H11	4
2004	2006	MAXIMA	-	-	H3	4
2015	2015	MICRA	H4	*	H11	-
2015	2016	MURANO	H11	H9	H11	-
2011	2014	MURANO	H11	9005	H8	-
2009	2010	MURANO	H11	9005	H8	-
2003	2007	MURANO	9007	*	9006	-
2012	2016	NV1500-3500	H13	*	-	-
2013	2016	NV200	H13	*	-	-
2013	2016	PATHFINDER	H11	9005	H11	-
2005	2012	PATHFINDER	9007	*	H11	-
2011	2016	QUEST	H11	9005	H8	-
2004	2009	QUEST	9006	9005	H11	-
2014	2016	ROGUE	H11	H9	H11	-
2011	2013	ROGUE	H11	9005	H8	-
2008	2010	ROGUE	H11	9005	H11	-
2014	2015	ROGUE SELECT	H11	9005	H8	-
2013	2016	SENTRA	H11	H9	H11	-
2004	2012	SENTRA	H13	*	H11	-
2016	2016	TITAN XD	H11	9005	H11	-
2011	2015	TITAN	9006	9005	880	-
2004	2010	TITAN	9006	9005	-	-
2012	2016	VERSA	H4	*	H11	-
2007	2011	VERSA	H4	*	H8	-
2014	2016	VERSA NOTE	9007	*	H11	-
2005	2015	XTERRA	9007	*	H11	-
Start	End	OLDSMOBILE				
Start	End	PONTIAC				
2001	2005	AZTEK	9006	9005	880	-
1999	2005	BONNEVILLE	9006	9005	H3 880	-
2007	2010	G5	9007	*	H11	-
2008	2010	G6	H11	H9	-	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2005	2007	G6	H11	H9	H11	-
2008	2009	G8	H11	H9	-	-
2004	2008	GRAND PRIX	9006	9005	H11	-
2004	2006	GTO	H11	H9	-	-
2005	2009	MONTANA	H11	H11	-	-
2006	2009	SOLSTICE	H13	*	-	-
2003	2005	SUNFIRE	H11	H9	880	-
2006	2009	TORRENT	H13	*	H11	-
2009	2010	VIBE	9006	9005	H10	-
					H11	-
2003	2008	VIBE	H4	*	9006	-
Start	End	PORSCHE				
2013	2016	911	-	H7	-	-
2009	2012	911	-	H11	-	-
2009	2012	911 w/ adaptive H/L	-	H7	-	-
2005	2008	911	H7	H9	H8	-
2005	2008	911 w/ HID	-	H11	H8	-
2013	2016	BOXSTER	H7	H9	-	-
2009	2012	BOXSTER	H7	H9	H8	-
2016	2016	BOXSTER w/ HID	-	H7	-	-
2009	2012	BOXSTER w/ HID	-	H7	H8	-
2005	2008	BOXSTER	H7	H9	H8	-
2005	2008	BOXSTER w/ HID	-	H11	H8	-
2015	2016	CAYENNE	-	H7	H11	H7
2003	2014	CAYENNE	H7	H7	H11	-
2014	2016	CAYMAN	H7	H9		-
2014	2016	CAYMAN w/ HID	-	H7	-	-
2009	2012	CAYMAN	H7	H9	H11	-
2009	2012	CAYMAN w/ HID	-	-	H11	-
2006	2008	CAYMAN	H7	H9	H11	-
2006	2008	CAYMAN w/ HID	-	H11	H11	-
2015	2016	MACAN	H7	H7	H11	-
2010	2016	PANAMERA	-	H7	-	H7
Start	End	RAM				
2012	2015	C/V	H11	H11	-	-
2011	2011	DAKOTA	H13	*	-	-
2013	2016	PICKUP w/o PROJECTOR H/L	H11	9005	H10	-
2013	2016	PICKUP w/ PROJECTOR H/L	9005	9005	9006	-
2011	2012	PICKUP	H13	*	H10	-
2011	2012	PICKUP w/ 4 H/L	H11	9005	H10	-
2014	2016	PROMASTER	H7	H7	H11	-
2014	2016	PROMASTER CITY	H11	9005	H11	-
Start	End	SAAB				
2005	2006	9-2X	H1	9005	9006	-
2009	2011	9-3	H11	H7	H8	-
2004	2007	9-3	H7	H7	H3	-
2010	2011	9-5	H7	9005	H10	-
2008	2009	9-5	H7	H7	H8	-
2006	2007	9-5	H7	H7	H8	-
2003	2005	9-5	H7	H7	H1	-
2005	2009	9-7X	H11	9005	H11	-
Start	End	SATURN				
2007	2009	AURA	H11	9005	H11	-
2003	2007	ION	9007	*	-	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2003	2005	L SERIES	H11	9005	-	-
2007	2010	OUTLOOK	H11	9005	H11	-
2007	2010	SKY	H11	H9	H11	-
2008	2010	VUE	H11	9005	H8	-
2002	2007	VUE	9006	9005	880	-
Start	End	SCION				
2013	2016	FR-S	H11	9005	-	-
2016	2016	iA	H4	*	H11	-
2012	2015	iQ	H11	9005	-	-
2009	2013	tC	H11	9005	-	-
2008	2008	tC	9006	9005	-	-
2008	2008	tC w/ PROJECTOR H/L	H11	9005	-	-
2005	2007	tC	9006	9005	-	-
2004	2006	xA	H4	*	9006	-
2008	2015	xB	H11	9005	-	-
2004	2006	xB	H4	*	9006	-
2008	2014	xD	H4	*	-	-
Start	End	SMART				
2016	2016	FORTWO	H4	*	H16	-
2008	2015	FORTWO	H7	H7	H11	-
2005	2007	FORTWO	H7	H1	H3	-
Start	End	SUBARU				
2006	2007	B9 TRIBECA	H7	H9	H3	-
2003	2006	BAJA	9007	*	9006	-
2003	2006	BAJA w/ 4 H/L	H1	9005	9006	-
2016	2016	CROSSTREK	H11	9005	H11	-
2016	2016	FORESTER	H11	9005	H11 H16	-
2014	2015	FORESTER	H11	9005	H16	-
2009	2013	FORESTER	H11	9005	9006	-
2006	2008	FORESTER	H1	9005	9006	-
2003	2005	FORESTER	H4	*	H3	-
2016	2016	IMPREZA	H11	9005	H11	-
2012	2015	IMPREZA	H11	9005	-	-
2008	2011	IMPREZA	H11	9005	9006	-
2006	2007	IMPREZA	H7	9005	H3	-
2004	2005	IMPREZA	H1	9005	H3	-
2015	2016	LEGACY	H11	9005	H11 H16	-
2013	2014	LEGACY	H7	9005	H16	-
2010	2012	LEGACY	H7	9005	H11	-
2008	2009	LEGACY	H7	9005	9006	-
2005	2007	LEGACY	H7	9005	H3	-
2015	2016	OUTBACK	H11	9005	H11 H16	-
2010	2014	OUTBACK	H7	9005	H11	-
2005	2009	OUTBACK	H7	9005	9006	-
2008	2014	TRIBECA	H7	9005	H3	-
2015	2016	WRX	H11	9005	H11 H16	-
2011	2014	WRX	H11	9005	9006	-
2008	2010	WRX	H11	9005	9006	-
2006	2007	WRX	H7	9005	H3	-
2004	2005	WRX	H1	9005	H3	-

Click on the model number of your headlight to see all the options available.

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2015	2016	WRX STI	-	9005	H11	-
					H16	
2008	2014	WRX STI	H11	9005	9006	-
2006	2007	WRX STI	-	9005	H3	-
2004	2005	WRX STI	-	9005	H3	-
2013	2015	XV CROSSTREK	H11	9005	-	-
Start	End	SUZUKI				
2005	2007	AERIO	H4	*	H8	-
2009	2012	EQUATOR	9007	*	H11	-
2004	2008	FORENZA	H7	H1	-	-
2006	2013	GRAND VITARA	H7	9005	H11	-
2001	2005	GRAND VITARA	H4	*	H3	-
2010	2013	KIZASHI	H7	H7	H11	-
2005	2008	RENO	H7	H1	-	-
2004	2010	SWIFT	H4	*	-	-
2007	2013	SX4	9007	*	H11	-
2004	2006	VERONA	H7	9005	-	-
2007	2009	XL-7	H13	*	H11	-
2006	2006	XL-7	H4	*	H11	-
2002	2005	XL-7	H4	*	H3	-
Start	End	TESLA				
2012	2016	MODEL S	9005	*	-	-
Start	End	TOYOTA				
2014	2016	4RUNNER	H11	9005	H16	-
2010	2014	4RUNNER	H11	9005	H11	-
2006	2009	4RUNNER	H11	9005	9006	-
2003	2005	4RUNNER	9006	9005	9006	-
2016	2016	AVALON	9005	9005	-	-
2013	2015	AVALON	9005	9005	H11	-
2011	2012	AVALON	H11	9005	H11	-
2008	2010	AVALON	H11	-	H11	9
2005	2007	AVALON	9006	9005	9006	-
2015	2016	CAMRY	H11	9005	-	-
2012	2014	CAMRY	H11	9005	H11	-
2007	2011	CAMRY INCL. HYBRID	H11	9005	H11	-
2002	2006	CAMRY	9006	9005	9006	-
2003	2005	CELICA	H7	9005	H3	-
2014	2016	COROLLA	-	9005	H16	-
2009	2013	COROLLA	9006	9005	H11	-
2005	2008	COROLLA	9006	9005	9006	-
2003	2005	ECHO	H4	*	9006	-
2007	2014	FJ CRUISER	H4	*	-	-
2014	2016	HIGHLANDER	H11	9005	H16	-
2011	2013	HIGHLANDER	H11	9005	-	-
2008	2010	HIGHLANDER	H4	*	H11	-
2004	2007	HIGHLANDER	9006	9005	9006	-
2013	2015	LAND CRUISER	-	9005	H16	-
2008	2011	LAND CRUISER	H11	9005	9006	-
1999	2007	LAND CRUISER	9006	9005	9006	-
2009	2014	MATRIX	9006	9005	H11	-
2003	2008	MATRIX	9006	9005	9006	-
2003	2005	MR2 SPYDER	H7	9005	9006	-
2012	2015	PRIUS	H11	9005	H16	-
2010	2011	PRIUS	H11	9005	H11	-

Year Range		Auto Make/Model	Low	High	Fog	Cornering
2006	2009	PRIUS	H4	*	9006	-
2004	2005	PRIUS	H4	*	9006	-
2012	2014	PRIUS C	H11	9005	H16	-
2015	2016	PRIUS V	H11	9005	H16	-
2012	2014	PRIUS V	H11	9005	-	-
2016	2016	RAV4	-	-	H16	-
2013	2015	RAV4	9005	9005	H16	-
2006	2012	RAV4	9006	9005	H11	-
2001	2005	RAV4	H4	*	-	-
2008	2016	SEQUOIA	H11	9005	H10	-
2001	2007	SEQUOIA	H4	*	9006	-
2011	2016	SIENNA	H11	9005	H11	-
2006	2010	SIENNA	9006	9005	9006	-
2004	2005	SIENNA	9006	9005	H3	-
2007	2008	SOLARA	H11	-	H11	-
2004	2006	SOLARA	H11	9005	H10	-
2016	2016	TACOMA	H11	H9	H11 H16	-
2012	2015	TACOMA	H4	*	H11	-
2004	2011	TACOMA	H4	*	H10	-
2014	2016	TUNDRA	H4	*	H16	-
2007	2013	TUNDRA	H11	9005	H10	-
1999	2006	TUNDRA	H4	*	9006	-
2013	2016	VENZA	H11	9005	H11	--
2009	2012	VENZA	H11	9005	H11	-
2015	2016	YARIS	H4	*	H16	-
2006	2014	YARIS	H4	*	H11	-
Start	End	VOLKSWAGEN				
2012	2016	BEETLE	H4	*	H8	-
2006	2010	BEETLE	H7	H7	H11	-
2003	2005	BEETLE	H1	H1	H1	-
2014	2016	CC	-	-	H8 9006	H7
2012	2013	CC	-	-	H8	-
2009	2011	CC	H7	H7	H11	-
2014	2015	CC R-LINE	-	-	9006	H7
2012	2016	EOS	H7	H7	9006	-
2007	2011	EOS	H7	H7	9006	-
2016	2016	E-GOLF	H7	-	-	H7
2015	2016	GOLF	H7	-	H11	H7
2010	2014	GOLF	H7	-	9006	-
2003	2009	GOLF	H7	H7	H3	-
2016	2016	GOLF SPORTWAGEN	-	H7	H11	H7
2015	2016	GTI	H7	-	-	H7
2010	2014	GTI	H7	-	9006	-
2006	2009	GTI	H7	H7	9006	-
2003	2005	GTI	H7	H7	H3	-
2015	2016	JETTA	H7	H7	H8	H7
2013	2014	JETTA	H7	H7	H8 9006	-
2011	2012	JETTA	H7	H7	9006	-
2010	2010	JETTA	H7	H7	9006	-
2006	2009	JETTA	H7	H7	9006	-
2010	2014	JETTA SPORTWAGEN	H7	-	9006	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2016	2016	PASSAT	H7	H9	H8	-
2012	2015	PASSAT	H7	H7	H8	-
2006	2010	PASSAT	H7	H7	9006	-
2002	2005	PASSAT	H7	H7	H3	-
2009	2010	PASSAT CC	H7	H7	H11	-
2004	2006	PHAETON	-	-	H11	-
2008	2008	R32	H7	H7	9006	-
2006	2009	RABBITT	H7	H7	9006	-
2010	2014	ROUTAN	H11	H11	-	-
2009	2009	ROUTAN	H11	H11	H10	-
2012	2016	TIGUAN	H7	-	9006	-
2009	2011	TIGUAN	H7	H7	9006	-
2015	2016	TOUAREG	-	-	H11	-
2011	2014	TOUAREG	-	-	9006	-
2004	2010	TOUAREG	H7	H9	H11	-
2004	2010	TOUAREG w/ HID	-	H7	H11	-
Start	End	VOLVO				
2012	2013	C30	H11	9005	H8	-
2012	2013	C30 w/ ADAPTIVE HID	-	H7	H8	-
2010	2011	C30	H7	H9	H8	-
2010	2011	C30 w/ ADAPTIVE HID	-	H7	H8	-
2007	2009	C30	H11	9005	H11	-
2011	2013	C70	H11	9005	H8	-
2011	2013	C70 w/ HID	-	H7	H8	-
2011	2013	C70 w/ ADAPTIVE HID	-	H7	H8	-
2006	2010	C70	H11	9005	H11	-
2006	2010	C70 w/ HID	-	H7	H11	-
2008	2011	S40	H11	9005	H8	-
2008	2011	S40 w/ HID	-	H7	H8	-
2005	2007	S40	H11	9005	H11	-
2005	2007	S40 w/ HID	-	H7	H11	-
2014	2016	S60	H7	H9	-	-
2012	2013	S60	H11	H9	-	-
2011	2011	S60	H7	H9	-	-
2007	2009	S60	H11	H9	H1	-
2005	2006	S60	H11	H9	H1 H3	-
2014	2016	S80	H7	H9	-	-
2014	2016	S80 w/ HID	-	H7	-	-
2012	2013	S80	H11	H9	H8	-
2012	2013	S80 w/ HID	-	H7	H8	-
2007	2011	S80	H7	H9	H8	-
2007	2011	S80 w/ HID	-	H7	H8	-
2004	2006	S80	H7	H7	H1	-
2004	2006	S80 w/ HID	-	9005	H1	-
2008	2011	V50	H11	9005	H8	-
2008	2011	V50 w/ HID	-	H7	H8	-
2005	2007	V50	H11	9005	H11	-
2015	2016	V60	H7	H9	-	-
2007	2010	V70	H11	H9	H8	-
2007	2010	V70 w/ HID	-	H7	H8	-
2005	2006	V70	H11	H9	H1 H3	-
2014	2016	XC60	H11	H9	-	-

Click on the model number of your headlight to see all the options available.



Year Range		Auto Make/Model	Low	High	Fog	Cornering
2014	2016	XC60 w/ HID	-	H7	-	-
2010	2013	XC60	H11	H9	H8	-
2010	2013	XC60 w/ HID	-	H7	H8	-
2016	2016	XC70	H7	H9	-	-
2014	2015	XC70	H11	H9	-	-
2014	2016	XC70 w/ HID	-	H7	-	-
2007	2013	XC70	H11	H9	H8	-
2007	2013	XC70 w/ HID	-	H7	H8	-
2005	2006	XC70	H11	H9	H1	-
					H3	
2016	2016	XC90	H11	H9	-	-
2013	2014	XC90	H11	H7	-	-
2007	2012	XC90	H11	H7	H1	-
2007	2012	XC90 W/HID	-	H9	H1	-
2003	2006	XC90	H11	H7	H1	-

Click on the model number of your headlight to see all the options available.