

# Chevrolet Silverado/GMC Sierra LED Pod Ditch Light Kit



Thank you for your purchase of our new LED Pod Ditch Light Kit. CAD-designed to use existing mounting points, this kit is compatible with the 2014-2018 Chevrolet Silverado 1500/GMC Sierra 1500 and 2019 Chevrolet Silverado 1500 LD/GMC Sierra 1500 Limited. Basic installation instructions are included below.

**Please contact us if you have any questions.**

COMPUTER DESIGNED  
**OEM FITMENT**



1. Open the hood and mark the location of the hood hinges with tape and tape the edges of the hood to prevent scratching.



2. Working on one side of the vehicle at a time, loosen the two 13mm flange bolts as necessary to fit the bracket (removing the nuts completely is not required). Be sure to support the rear edge of the hood during the install.



3. Place the ditch light bracket under the hinge and align the holes with hood hinge. Adjust the bracket to leave a slight gap at the back of the hood; it should not touch the plastic cowl.

**NOTE:** The bracket may slightly contact the rubber overlay on the plastic cowl section. Ensure the bracket does not interfere with the plastic underneath.

*See back for further instructions.*



4. Secure the bracket and hood hinge by tightening the factory nuts, ensuring the hood hinge lines up with the tape.

Repeat the steps on the other side of vehicle.



5. Verify bracket and hood fitment. Carefully close the hood ensuring no contact is made with the bracket and the plastic cowl. Confirm the hood latches properly and gaps are uniform with the fenders. Turn on windshield wiper to confirm clearance from the ditch light bracket. If fitment is not satisfactory, adjust hood and/or bracket position as desired.



6. Once the bracket is mounted to the hood, refer to the Universal Bracket Info/Mounting Guide to mount your pod onto the bracket.

A small cutout has been designed on each bracket to aid in wire routing. Use the included zip-tyes to secure the wiring away from the hood hinge.

**NOTE:** Do not use automatic car washes with this kit installed.

Please contact **Diode Dynamics** should you have any questions about the installation or wiring process, at **314-205-3033** (10a-5p CST) or **contact@diodedynamics.com**.

### **NEED MORE HELP?**

**Scan the QR code to link to our YouTube Channel!**

We continuously bring in vehicles to our testing garage in order to create step-by-step videos to walk you through the installation process on your specific vehicle. Scan the QR code to see all our installation videos. Be sure to subscribe to our channel to stay up-to-date on the newest products and videos from Diode Dynamics!

**YouTube**



### **This installation guide is for the following SKUs:**

DD6654 Silverado/Sierra Ditch Light Brackets  
DD6655 Silverado/Sierra Ditch Light Kit SS3 Sport White Driving  
DD6656 Silverado/Sierra Ditch Light Kit SS3 Sport Yellow Driving  
DD6657 Silverado/Sierra Ditch Light Kit SS3 Pro White Driving  
DD6658 Silverado/Sierra Ditch Light Kit SS3 Pro Yellow Driving

DD6659 Silverado/Sierra Ditch Light Kit SSC2 Sport White Combo  
DD6660 Silverado/Sierra Ditch Light Kit SSC2 Sport Yellow Combo  
DD6661 Silverado/Sierra Ditch Light Kit SSC2 Pro White Combo  
DD6662 Silverado/Sierra Ditch Light Kit SSC2 Pro Yellow Combo

**100% SATISFACTION  
GUARANTEE**

