



INSTALLATION INSTRUCTIONS

PART No. FB23194F & FB33195F

**Jeep® JL Wrangler & JT Gladiator
JL & JT Front Elite Fenders**



REQUIRED TOOLS

- 5mm Allen
- 3mm Allen

Note: These instructions will **NOT** cover how to remove factory fenders or inner fenders, and will **NOT** cover how to install inner fenders. Instructions on how to do so are available on www.FishboneOffroad.com , or www.FishboneOffroad.tv .

KIT CONTAINS

- Front Fender (Left & Right)
- LED Turn Signal
- Rubber Seal
- LED Retaining Bracket
- M8 25mm Button Head Bolt
- M8 Flat Washer
- M8 Serrated Nut
- M5 30mm Button Head Bolt
- M5 14mm Button Head Bolt
- M5 Flat Washer
- M5 Serrated Nut

QTY

- 2
- 2
- 2
- 2
- 24
- 24
- 24
- 4
- 4
- 8
- 8

23194F & FB33195F00

INSTALLATION INSTRUCTIONS

PART No. FB23194F & FB33195F

**Jeep® JL Wrangler & JT Gladiator
JL & JT Front Elite Fenders**

1) REMOVE

Begin by removing any inner and outer fenders your vehicle currently has installed.




2) PREPARE

The included rubber seals are driver and passenger side specific. Identify which side which is which by the bolt hole indents in the rubber. Peel off the backing and carefully apply the seal to the vehicle side wall of each fender.



Install the included LED lights into their slots. Place the retaining bracket in between the fender brackets, and loosely secure it with 2 of the smaller m5 bolts, washers, and nuts.



Next, insert the light through the slot and into the bracket so that the LEDs with the directional lenses are closest to the vehicle side of the fender.



Push it into the bracket, pulling the wire through it, and secure it to the bracket with the 2 longer m5 bolts, washers, and nuts.



The alignment will be adjusted after the fender is installed.

INSTALLATION INSTRUCTIONS

PART No. FB23194F & FB33195F

**Jeep® JL Wrangler & JT Gladiator
JL & JT Front Elite Fenders**

3) **INSTALL FRONT FENDERS**

Hold the corresponding fender up to the vehicle and begin loosely securing it with 12 of the included M8 bolts, washers, and serrated nuts.



Repeat on the opposite side

4) **ENJOY YOUR NEW FISHBONE OFFROAD JL & JT FRONT FENDERS**

Connect the turn signal's power to the vehicle. Remove the tape backing on the power converter and secure it to your vehicle as desired.



With the fender installed, test the alignment of the light. Move the light around as desired and secure its angle by tightening the vertical and horizontal bolts with a 3mm allen.