



## Pontiac G8 Radiator Cover Installation Instructions

Step 1. Insert Radiator cover by tilting cover and engaging under the W/W fluid cap. (blue cap) After the cover is under the blue cap, align with the fastening holes.



Step 2. If necessary, align the yellow coolant tank cap with the cut out in the radiator cover. Use the supplied cable tie to align the coolant neck.

Step 3. Insert the four push fasteners to secure the cover. if the lip of the cover is not hooked under one of the protrusions on the W/W fill tube. Adjust if necessary.

To remove the cover, use a screwdriver to pry up the center "nail" of the fastener. It will need to be pulled upward apprx. 1/2" to release from the fastening point. Next, gently pry up on the body of the fastener to remove it.

