

CAMARO COLD AIR INTAKE SYSTEM FOR MAGNUSON HEARTBEAT S/C

The Magnuson Heartbeat intake installs using the normal Roto-fab CAI system installation instructions until you reach the elbow installation. **Important! The breather fitting bung will locate to the MAF sensor side and will be on the underneath side once installed.**

Before installing the inlet elbow, install the small 90 degree fitting into the 1/4" NPT breather bung into the inlet elbow. Tighten so the small fitting will be pointing to the right side (passenger side) approximately parallel to the radiator. Note this fitting is not designed to "bottom out". One end of the supplied breather hose can be installed on the small fitting at this time. (see ill.)

With the throttle body step hose and the MAF sensor housing hump hose already installed and hose clamps in place, install the inlet elbow by engaging the MAF housing hump hose with the opposite end of the elbow facing straight up. **Be sure the breather fitting will end up on the bottom side.** Once fully engaged in the hump hose, roll the tube downward to engage the throttle body step hose. Position the tube for optimum alignment and tighten the hose clamps. (do not overtighten)

Route the breather hose to the valve cover breather nipple using the route shown. Use the supplied cable ties to secure the breather hose as necessary, but leave enough slack to allow the hose to move freely during motor rock. If you are doing a complete intake install, proceed to step 8 in the CAI instructions.

