


## **INSTALLATION INSTRUCTIONS**

## **IGNITE FLUSH MOUNT**

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems. Professional installation is recommended.

- 1. Use 1.75" diameter hole saw for main hole.
- 2. Place light into hole and mark locations for mount screws. Use 3/16" drill bit for mount screw holes.
- 3. Install lamps using provided hardware.
- 4. Wiring: Red = positive. Black = negative. 5 Amp in-line fuse is recommended.

Take care to avoid any heat sources & sharp or abrasive surfaces.



Use This Template For Accuracy When Using Hole Saw

## WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty 779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337 www.rigidindustries.com

Ignite and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.