

GM 2019-2020 1500 and 2020 GM 2500/3500

Thank you for choosing Rough Country for all your vehicle needs.

If questions exist we will be happy to answer any questions concerning the design, function, and correct use of this product, please call us @1-800-222-7023.

READ BEFORE USING YOUR ROUGH COUNTRY IN-LINE SPEEDOMETER CALIBRATOR MODULE





Rough Country Inline Speedometer Calibrator Module Installation Instructions PN 90045 2019-2020 GM 1500 and 2020 GM 2500/3500

This installation manual shows an example installation on a 2019 Chevrolet 1500 New Style truck. The installation may vary for your vehicle, so it may be necessary to consult a GM service manual for specific instructions for your year model.

Be advised: These instructions may not include specifics for all vehicle configurations. Access our website to update your programmer.

This step makes sure that the programmer has the latest firmware installed. If Tuner Update Software is not already
installed on your PC, go to our website and download the update software. Connect the Speedometer Calibrator to
your PC with the supplied USB cable, run the update software and click the Update Tuner button.

vailable Vehicle Applications:	(\	Program Ur
Application Not Programmed Ford Escape 2005-2007		Read Devic
ord Escape 2008		
Ford Expedition 2007-2008		Exit
Ford F-150 2016-2018 Ford F-SuperDuty 2005-2007	+ Overall	Batio:
		11000.
Tires are non-stock	Gear Info Gears are no	n ataali
Old Tire Size NewTire Size		N-SLOCK
	Old Gear Batio	1:
2) ^{in.} (3)	in.	
	OR- New Gear Ratio:	:1
	B	
Dist		
Directions Connect the inline device to the PC.		
	A . P. J. JP.1	Í
Select the desired vehicle from the 'Available Vehicl	e Applications' list.	
f tires are non-stock, select the 'Tires are non-stock the tire information, you may enter the tire diameter in		on. Note that for
me the information, you may enter the the tilameter in	There's off the tiles aspect faile numbers.	
Status:		
** Application	on Not Selected **	
	or Gear Not Set	
	Ji Geal NUL Set	


2. For accurate readings, measure the stock and new tire height from the ground to the top of the tire. Enter these measurements (in inches) into the configuration software, and click program to commit these settings. Once configuration is complete, take the Speedometer Calibrator module and harness to the vehicle.



3. Looking up under the Driver's side dash, near the brake pedal, you will see a module with 7 color coded connectors. Remove the 1st White connector closest to you.



- 4. Plug the male end of the Inline Speedometer Module Harness into the female end of the OE Harness.
- 5. Plug the male end of the Speedometer Module Harness into the OE module and tuck the harness and Speedometer Module behind the kick panel.
- 6. Start vehicle and check to ensure proper function.



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items

listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

